PARTS LIST

for

Whirlpool CORPORATION

UNDERCOUNTER DISHWASHER

MODEL DU9200XX-1

Almond/Black

FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS

Whirlpool CORPORATION
Benton Harbor, Michigan.

© 1993 WHIRLPOOL CORPORATION

11/93

12-93 Litho in U.S.A.

Part No. 3370175 Rev. A

FRAME AND CONSOLE PARTS

For Model: DU9200XX-1



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	3369822	Console (Includes Item 2)
2	3369813	Insert, Console
3	3369362	Switch, Control
4	3369417	Motor, Dual
7	304231	Screw, 8-18 x 1/2 (6)
8	3368900	Door Frame
9	3369502	Bolt, Latch
10	3369503	Lever, Latch
11	3369325	Switch, (2)
12	3369504	Pin, Switch (2)
13	3369765	Harness and Protector (Includes Item 14)
14	3368977	Elbow, Harness
15	9412221	Screw, 8-32 x 1/4
16	3369192	Cover Timer
18	3368979	Spacer, Corrugated
19	3369516	Panel, Front (Almond/Black)
20	3370441	Retainer, Panel
22	3369598	Trim, Console
23	3369592	Trim (2)
24	3369530	Switch (1)
25	98997	Clip, Harness

|Refer To Dishwasher Replacement Panel Parts List No. 675345

INNER DOOR PARTS

For Model: DU9200XX-1



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	3369533	Inner Door (Also Order Latch Door Kit 676413)
2	3369060	Latch, Detergent Dispenser
3	3369061	Snap, Detergent Dispenser
4	3369505	Actuator Assembly
5	3369506	Wet Agent, Dispenser
7	3369448	Draw Bar, Electronic
8	3368999	Spring (Draw Bar)
9	3368981	Lid Assembly
10	300106	Spring, Lid
11	300115	Pin (Lid Hinge)
12	3369603	Screen, Vent
13	3369200	Wet-Agent Cap Assembly
14	3369155	Seal (Wet-Cap)
15	3369051	Screw (8)
16	3369068	Cover, Drip

TUB ASSEMBLY PARTS

For Model: DU9200XX-1



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	3370851	Tub Assembly
2	3369078	Tub, Wheel Assembly (8)
3	3368932	Runner (2)
4	302849	Leveler (2)
5	3370389	Screw, Shoulder (2)
6	302819	Wheel (2)
7	343641	Screw, 10-16 x 1/2 (4)
8	3368965	Plate, Latch
9	3368919	Screw, 8-32
10	3368994	Gasket
11	3369511	Retainer, Access Panel
12	3369052	Deflector (2)
13	3369416	Heater
14	717273	Washer, Rubber (2)
15	3369073	Nut (2) (Heater Terminal)
16	3369868	Water Valve
17	304392	Screw, 8-18 x 1/2
18	3369777	Thermostat, Hi-Limit
19	3370231	Thermostat
20	301958	Clamp
21	304666	Push Retainer
22	3369775	Retainer, Shield
23	90767	Screw, 8 x 3/8
24	3369447	Relay
25	304231	Screw, 8-18 x 1/2
26	3369617	Sound Shield
27	3368983	Shield, Harness
28	3369337	Spring & Bearing Assembly (2)
29	3369048	Housing, Float Switch
30	3369067	Switch, Float
31	3369049	Cover, Switch Housing
32	3369451	Float
33	717488	Nut
34	3369831	Toe Panel
35	3369193	Panel, Access
36	302868	Screw, 8-18 x 1/2 (4)
37	3369414	Hose, Inlet
38	304626	Drain Hose
39	3369317	Diverter
40	3369771	Sound Shield
41	3369332	Terminal Block & Plug Assembly
42	3371277	Cover Assembly, Terminal Box
43	3369527	Panel, Front (Almond/Black)
44	3369526	Spacer, Corrugated
45	3369531	Extension
46	3369593	Trim, Side (2)
47	3369588	Trim, Bottom
48	3370555	Bracket, Thermostat
49	3367052	Hose Clamp

Refer To Dishwasher Replacement Panel Parts List No. 675345

PUMP AND MOTOR PARTS

For Model: DU9200XX-1



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	302720	Plate, Perforated (Includes Item 5) (Also Order Item 30) See Note A.
2	3367173	Base, Inlet (Includes Items 1 & 5) (Also Order Item 30) See Note A.
3	303573	Screw, 8-18 x 5/8
4	302710	Seal, Inlet Base
5	302709	Ball, Check
6	95080	"O" Ring
7	302721	Cover, Valve
8	302738	Valve Stem Kit (Includes Items 12, 13 & 22) See Note A.
9	303883	Separator Assembly (Includes Items 12, 13 & 22) See Note A.
10	302717	Screw, 8-18 x 1-5/8 (4)
11	303510	Impeller, Wash (Includes Items 12 & 13)
12	3371152	Screw & Seal 10-32 x 3/4
13	302711	Seal, Pump Outlet
14	3369478	Outlet, Pump (Includes Item 13)
15	3369482	Check Valve (Includes Item 6)
16	717000	Gasket, Pump
17	3369475	Pump & Motor Assembly (Includes Item 16)
18	302707	Bushing, Grind
19	302718	Chopper Kit (Also Order Item 30) See Note A.
20	302705	Sleeve, Drain Impeller
21	718258	Screw, 8-18 x 5/8
22	302704	Seal, Drain Cover
23	302723	Cover, Drain (Also Order Item 30) See Note A.
24	303539	Impeller, Drain Kit (Also Order Item 30) See Note A.
25	3367204	Base, Pump (Includes Item 24) (Also Order ITEM 30) See Note A.
26	3367197	Support, Pump Mounting (4)
27	3368270	Slinger (See Note A.
28	3369472	Motor (Includes Item 27) (Also Order Item 30) (For Electrical Connector Only, See Wiring Harness Page.) See Note A.
29	3369331	Screw (4)
30	675505	Pump Seal Kit (Includes Items 4, 12, 13 & 22)
31	303918	Tool, Pump Centering

NOTE A: Pump Centering Tool Required For Pump Re-Assembling - Order Item 31.

DISHRACK PARTS

For Model: DU9200XX-1



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	303722	Clip
2	3368290	Support, Arm
3	3368300	Spray Arm, Upper
4	3368006	Bumper (2)
5	300848	Tower, Pressure
6	3369509	Wheel & Transport Assembly (4)
7	3370491	Dishrack, Lower (Includes Items 4 & 6)
8	3370075	Clip, Strap
9	3369488	Silverware Basket Assembly
10	3369485	Cover, Basket
11	300845	End Cap (Front or Rear)
12	3369071	Track
13	3369046	Stop, Track (2)
17	3369958	Wheel and Axle Assembly (4)
18	3368896	Dishrack, Upper
19	717528	Trim, Basket
20	300086	Handle, Basket
22	3369347	Sprayarm, Lower
23	3367910	Cap, Nozzle
24	719576	Bearing, Nozzle

Following Parts Not Illustrated and Optional Parts Not Included

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH UP (1/2 oz.)

72017	White
72107	Almond
72112	Black

PAINT, PRESSURIZED SPRAY (13 oz.)

350956	Almond
285006	Superior Black
206922	Primer (White)
350941	Leveler (Thinner)

PAINT, TOUCH UP (1 qt.)

978883	Almond (Uncut)
799340	Black (Uncut)

DISHRACK REPAIR

675476	Vinyl Touch-Up (Blue)
675506	Tine Tip Repair Kit (Blue - Enough For Two Complete Dishracks)

LITERATURE PARTS

LIT3369671	Instructions, Installation
LIT3367007	Instructions Installation (Supplement) (Locating Your Water Supply)
LIT3369100	Guide, Use & Care
LIT3370907	Energy Guide
LIT3370538	Tech Sheet
LIT3370175	Parts List

MISCELLANEOUS PARTS



MISCELLANEOUS PARTS

1	336981	Miscellaneous Parts Bag (Includes 2 Screws & 2 Hose Clamps)